

3201

Operation Manual

INSTALLATION MANUAL

Thermostat Applications Guide

Description	
Gas or Oil Heat	Yes
Electric Furnace	Yes
Heat Pump (No Aux. or Emergency Heat)	Yes
Heat Pump (with Aux. or Emergency Heat)	No
Multi-stage Systems	No
Heat Only Systems	Yes
Heat Only Systems - Floor or Wall Furnaces	Yes
Cool Only Systems	Yes
Millivolt	Yes

THERMOSTAT QUICK REFERENCE Page

Installation Manual	2
Installation Tips	3-5
Thermostat Quick Reference	6-8
Wiring	9-16
Technician Setup	17-19
Specifications	20

Power Type

Battery Power

Hardwire (Common Wire)


Hardwire (Common Wire) with Battery Backup

A trained, experienced technician must install this product.

Carefully read these instructions. You could damage this product or cause a hazardous condition if you fail to follow these instructions.

Wall locations

The thermostat should be installed approximately 4 to 5 feet above the floor. Select an area with average temperature and good air circulation.



Do not install thermostat in locations:

- Close to hot or cold air ducts
- That are in direct sunlight
- With an outside wall behind the thermostat
- In areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where there might be concealed chimneys or pipes

Tip

Pick an installation location that is easy for the user to access. The temperature of the location should be representative of the building.

Installation Tips



Caution: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.




Mercury Notice:

All of our products are mercury free. However, if the product you are replacing contains mercury, dispose of it properly. Your local waste management authority can give you instructions on recycling and proper disposal.


For vertical mount put one screw top and one screw bottom.

For horizontal mount put one screw left and one screw right.




Mount Thermostat

Align the 4 tabs on the subbase with corresponding slots on the back of the thermostat, then push gently until the thermostat snaps in place.



Battery Installation

Battery installation is optional if thermostat is hardwired (**C** terminal connected).



Replace with 2x AA Alkaline Batteries. High quality Alkaline batteries are recommended.

THERMOSTAT QUICK REFERENCE

Getting to know your thermostat



1 LCD Display
See page 6 for details about this display read out.

2 Fan Switch
Select **ON** or **AUTO**. **ON** will run the fan continuously. **AUTO** will cycle the fan on only when the heating or cooling system is on.

3 System Switch
Selects the operation mode on your **HEAT** system. Selecting **HEAT** turns on the heat mode. Selecting **COOL** turns on the cool mode. Selecting **OFF** turns both heating and cooling off.

4 Temperature Setpoint Buttons
Press the + or - buttons to select the desired room temperature.


5 Easy Change Battery Door



Use the finger bevel on the lower portion of the thermostat to open the easy access battery door.

THERMOSTAT QUICK REFERENCE

LCD



Battery Door Information



Caution:

When the battery icon  appears replace your 2x AA batteries immediately. Failure to do so may result in your heating & cooling system becoming inoperable. Freezing or overheating can occur.

THERMOSTAT QUICK REFERENCE

Terminal Designations

RH-----24VAC(system power supply)HEAT=RH TO W

RC-----COOL= RC to Y FAN=RC TO G

C-----Common24VAC (system power supply)

W-----HEAT


Y-----COOL

G-----FAN

B-----REV VALVE HEAT

O-----REV VALVE COOL


1 Turn Off Power to Heating/Cooling System



2 Remove Old Thermostat

Remove old thermostat but leave wallplate with wires attached.

Do not remove wallplate yet




WIRING

3 Label Wires with Tags

Label the wires using the supplied wire labels as you disconnect them.

Wiring Labels		Étiquettes de fils		Rótulos para los cables					
Apply these wiring labels to each wire with the appropriate terminal designation as you remove it from the existing thermostat.		Lorsque vous retirez les fils des bornes du thermostat existant, collez ces étiquettes sur chaque fil correspondant à la lettre de la borne.		Coloque estos rótulos, con la designación de las terminales, en cada cable al remover los cables del termostato actual.					
B	B	Y2	Y2	C	C	E	E	F	F
G	G	H	H	L	L	O	O	P	P
R	R	RC	RC	RH	RH	T	T	U	U
VVR	VVR	W	W	W1	W1	W2	W2	W3	W3
X	X	X1	X1	X2	X2	Y	Y	Y1	Y1
AUX	AUX								


Wire Labels



Terminal designation

4 Separate Wallplate from New Thermostat


Remove wallplate from the new thermostat and mount onto wall.



Wallplate

5 Separate Wallplate from New Thermostat

Mount the new wallplate using the included screws and anchors.



Drill 3/16-in. holes for drywall


Drill 3/16-in. holes for plaster

WIRING

6 Connect Wires


Simply match wire labels.

If labels do not match letters on the thermostat, check "Alternate Wiring (Conventional Systems)" on page 13 and connect to terminal as shown (see notes, below).



Alternate Wiring (Conventional Systems)

If labels do not match letters on the thermostat, check the chart below and connect to terminal as shown here (See notes, below).



- 1 If wires will be connected to both **RC** and **RH/R** terminals, remove metal jumper.
- 2 If there has **C** or **X** wire available then you can connect with **C** terminal, if there is no **C** or **X** wire then no need to connect with C terminal.
- 3 If you have a **heat pump** without auxiliary/backup heat connect **O** or **B**, not both. If you do not have a **heat pump**, do not connect **B**. Wrap bare end of wire with electrical tape.
- 4 Place a jumper (piece of wire) between **Y** and **W** if you are using a heat pump without auxiliary/backup heat

WIRING



Caution: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.



Warning:

All components of the control system and the thermostat installation must conform to Class II circuits per the NEC Code.

Wiring

1. If you are replacing a thermostat, make note of the terminal connections on the thermostat that is being replaced. In some cases the wiring connections will not be color coded. For example, the green wire may not be connected to the **G** terminal.
2. Loosen the terminal block screws. Insert wires then retighten terminal block screws.
3. Place nonflammable insulation into wall opening to prevent drafts.

Tips:

RH & RC terminals

For single transformer systems, leave the jumper wire in place between RH and RC. Remove jumper wire for two transformer systems.

Heat pump systems (With No AUX or Emergency Heat)

If wiring to a heat pump, use a small piece of wire (not supplied) to connect terminals W and Y.

Terminal Designations

- W** Heat relay **G** Fan relay **Y** Compressor relay
- O** Heat pump changeover valve energized in cooling
- RC** Transformer power for cooling
- RH** Transformer power for heating
- B** Heat pump changeover valve energized in heating
- C** Common wire from secondary side of cooling system transformer or for heat only system transformer

Wire specifications


Use shielded or non-shielded
18 - 22 gauge thermostat wire.

C terminal


The C (common wire) terminal does not have to be connected when the thermostat is powered by batteries.

- 1 Power supply
- 2 Factory-installed jumper. Remove only when installing on 2-transformer systems.
- 3 Use either O or B terminals for changeover valve
- 4 Use a small piece of wire (not supplied) to connect W and Y terminals
- 5 Set fan operation switch to electric
- 6 Optional 24 VAC common connection when thermostat is used in battery power mode

Typical 1H/1C system: 1 transformer




Typical 1H/1C system: 2 transformer




WIRING


Typical 1H/1C heat pump system




Typical heat-only system



Typical heat-only system with fan




Typical cool-only system





Select ELEC or GAS
with this switch



Gas or Electric Setup

Gas: For systems that control the fan during a call for heat, put the fan operation switch to the **GAS** position.

Electric: The thermostat operation switch should be put in the **ELEC** position. This setting allows the thermostat to operate the fan when the fan relay is connected to the **G** terminal.

TECHNICIAN SETUP

1. Select OFF with the system switch, hold down the “+” and “-” buttons together for 3 seconds to access
2. Press - to go to the next option
3. Press + to select the parameters you want to modify
4. To exit, move system switch or wait for 10 seconds.

Tech Setup Steps		LCD Will Show	Adjustment Options	Default
Room Temperature Calibration	This feature allows the installer to change the calibration of the room temperature display. For example, if the thermostat reads 70° and you would like it to read 72° then select +2.	Calibration 0 °F	You can adjust the room temperature display to read up to 4° above or below the factory calibrated reading.	0 °F
F or C	Select for Fahrenheit temperature read out select C for Celsius read out.	0F	F for Fahrenheit C for Celsius	0F
Compressor Short Cycle Delay	The compressor short cycle delay protects the compressor from short cycling. This feature will not allow the compressor to be turned on for 3 minutes after it was last turned off.	00 Com Delay	Selecting ON will not allow the compressor to be turned on for 3 minutes after the last time the compressor was switched off. Select OFF to remove this delay.	00

1. Set the thermostat system switch to the desired position (COOL or HEAT).
2. Press and hold “+” and “-” together for 3 seconds.
3. Use “+” and “-” to adjust desired swing setting (The display reads in tenths of a degree.)
4. To exit, move system switch or wait for 10 seconds.

Tech Setup Steps		LCD Will Show	Adjustment Options	Default
Cooling Swing (SYSTEM COOL)	The swing setting, often called “cycle rate”, “differential” or “anticipation” is adjustable. A smaller swing setting will cause more frequent cycles and a larger swing setting will cause fewer cycles.	05 °F Cool Swing	The cooling swing setting is adjustable from 0.2° to 2°. For example: A swing setting of 0.5° will turn the cooling on at approximately 0.5° above the setpoint and turn the cooling off at approximately 0.5° below the setpoint.	05 °F
Heating Swing (SYSTEM HEAT)	The swing setting, often called “cycle rate”, “differential” or “anticipation” is adjustable. A smaller swing setting will cause more frequent cycles and a larger swing setting will cause fewer cycles.	04 °F Heat Swing	The heating swing setting is adjustable from 0.2° to 2°. For example: A swing setting of 0.4° will turn the heating on at approximately 0.4° below the setpoint and turn the heating off at approximately 0.4° above the setpoint.	04 °F

Tip

Temperature swing, sometimes called differential or cycle rate, can be customized for this individual application. For most applications choose a swing setting that is as long as possible without making the occupants uncomfortable.

SPECIFICATIONS

Specifications

The display range of temperature	41°F to 95°F (5°C to 35°C)
The control range of temperature	44°F to 90°F (7°C to 32°C)
Load rating	1 amp per terminal, 1.5 amp maximum all terminals combined
Display accuracy	± 1°F
Swing (cycle rate or differential)	Heating is adjustable from 0.2°F to 2.0°F Cooling is adjustable from 0.2°F to 2.0°F
Power source	18 to 30 VAC, NEC Class II, 50/60 Hz for hardwire (common wire) Battery power from 2 AAA Alkaline Energizer batteries
Operating ambient	32°F to +105°F (0°C to +41°C)
Operating humidity	90% non-condensing maximum
Dimensions of thermostat	4.72"W x 3.86"H x 0.98"D

Operation Manual